

ECOFLOW GATEWAY (SINGLE-PHASE)



For the latest documents, please scan the QR code or visit:
Q <https://energy.ecoflow.com/au/documentation>

IMPORTANT

- Before installing, operating, and maintaining the equipment, read and follow Installation Guide.

CONTENTS

01	Safety Instructions
01	Disclaimer
01	Symbols
03	Product Introduction
03	Product Features
03	Appearance
03	Maintenance Compartment and Wiring Terminals
04	System Deployment
07	Schematic Diagram
07	System Operating Mode
08	Preparing Tools and Instruments
08	What's In The Box
09	System Installation
09	Installation Space Requirements
09	Wall Mount
10	Electrical Connection
10	Preparing Cables
12	Recommended Routing
12	Opening the Maintenance Compartment
13	Connecting Power Grid / Backup household loads / Non-Backup household loads /Smart Load / Generator
13	Installing the Signal Cable
17	System Commissioning
17	Check Before Power-On
17	Closing the Maintenance Compartment
17	System Power-On
18	System Maintenance
18	System Power-Off
18	Routine Maintenance
19	Bypass Switch Operating Instructions
20	Technical Parameters

SAVE THESE INSTRUCTIONS

This manual contains important instructions that shall be followed during installation and maintenance.

Safety Instructions






I Disclaimer

This product includes essential printed documentation required for setup and basic usage. For detailed manuals, resources, and the most up-to-date information about the product, visit <https://homebattery.ecoflow.com/documentation>. Fully read and understand the product documentation prior to use. Improper use may result in serious injury, damage, or property loss. By using this product, you agree to and accept all terms outlined in the product documentation. EcoFlow is not liable for losses, damages, or injuries caused by misuse or non-compliance.

I Symbols

The shell or nameplate of this product includes safety symbols to indicate potential hazards. Please review these signs and their meanings as detailed in the table below:

* "This product" or "the device" refers to the EcoFlow Gateway (Single-Phase) throughout this document.

Symbol	Description
	CAUTION Disconnect the device from all voltage sources before servicing.
	Risk of Electric Shock
	Reading Manual Read the user manual and all safety instructions carefully before installation, operation, and maintenance.
	CE Marking The device complies with the essential requirements of the relevant EU legislation.
	WEEE Directive Do not dispose of the device as household waste. Follow local electronic waste disposal regulations.




- Before installing, operating, and maintaining the equipment, read and follow Installation Guide.
- All operating and wiring must comply with national and local requirements of the relevant standards.
- Personnel who plan to install or maintain EcoFlow equipment must receive thorough training, understand all necessary safety precautions, and be able to correctly perform all operations.
- Personnel who will install, operate, and maintain the equipment, including operators, trained personnel, and professionals, should possess the local national required qualifications in special operations such as high-voltage operations, working at heights, and operations of special equipment.
- Before connecting cables, ensure that the equipment is intact. Otherwise, electric shocks or fire may occur.
- Before installing, operating, and maintaining the equipment, always disconnect all sources of supply before proceeding.
- Wear proper PPE (Personal protective equipment) before any operations.
- Do not work with power on during installation or maintenance.
- Do not touch the exposed electrical cable or parts with bare hands.
- **GROUNDING INSTRUCTIONS:** This product must be grounded. If it should malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock.
- Do not use any unofficial or unrecommended components or accessories. For any replacements, please contact EcoFlow for further assistance.
- Please use the preset holes of this product. Do not drill holes or modify the frame yourself. Otherwise, the warranty will be voided.
- Install the product in a tidy, dry, and well-ventilated environment.
- Follow the environment temperature requirements specified in the product specification to use or store the product. Avoid degradation or damage to the product, or risks to personal safety due to excessively high or low temperatures.
- Do not wet the product, or leave it in a humid environment for an extended period of time. Do not allow the junction box or wire connectors to come into contact with liquids.
- Keep the product out of the reach of children and pets.
- Do not pierce the product with sharp objects.
- Do not insert wires or other metal objects into the product to prevent short circuits.




- Do not disassemble, repair, or modify this product by yourself. For any maintenance or service, contact the EcoFlow Customer Service.
- Do not scrawl, damage, or block any warning labels on the product.
- Do not clean the product with flammable or toxic solvents. Wipe it with a dry soft cloth.



AVOID DIRECT
SUNLIGHT, RAIN, OR
SNOW




DO NOT MOUNT IN A
CROOKED MANNER.




AVOID THE WATER
PIPES AND POWER
CABLES



AWAY FROM SOLVENT/
GASOLINE/HEAT
SOURCE/MOISTURE/
EXPLOSIVE MATERIAL/
FLAMMABLE
MATERIAL/INFRARED
RADIATION




WELL-VENTILATED
AREA ONLY



IP55

0%-100% RH
-30°C -55°C



ALTITUDE

≤3000m


Product Introduction

I Product Features

EcoFlow Gateway (single-phase) is a smart backup module that works with EcoFlow PowerOcean single-phase home solar battery systems to build a whole home backup system. In this setup, PowerOcean (single-phase) inverter controls operation of the system, while the Gateway monitors energy usage and manages the switchover between on-grid and off-grid modes. Additionally, the Gateway is compatible with ecologically compatible products such as EcoFlow PowerPulse 2 EV Charger, generator and third-party PV system.


I Appearance


- ⚠ Before maintenance, power off the main circuit breaker, the inverter, and the DC switches of the inverter and battery.



I Maintenance Compartment and Wiring Terminals

- ⚠ *1 Only authorized personnel can open the maintenance compartment cover to perform electrical connections.
- *2 During deployment and normal use, do not operate the bypass switch. Ensure that the bypass switch is off.
- *3 Use preset cable entries. Do not modify the module frame without permission, otherwise this may void the warranty.






I System Deployment


PLAN OF LOADS CONNECTED TO THE GATEWAY




- For a main breaker $\leq 63A$, all loads can be connected to the Gateway. For a main breaker $>63A$, only some of loads are permitted.
- If the generator deployed in the system runs in off-grid mode, make sure the load power is within the generator capacity, otherwise the generator may shut down due to overload.
- Backup loads exceeding off-grid capacity may trip the inverter. Disconnect loads or move low-priority ones to non-backup ports.





RESIDENTIAL WIRING DIAGRAMS



SYSTEM OVERVIEW (WITH ALL LOADS CONNECTED TO THE GATEWAY)



SYSTEM OVERVIEW (WITH SOME OF LOADS CONNECTED TO THE GATEWAY)





OFF-GRID OPERATING CAPACITY

Off-grid max power is capped by the inverter (e.g., 6 kW) and ESS capacity (e.g., 15 kWh).






- When the inverter is off-grid, make sure the peak load current and duration are within the off-grid running capability of the inverter.




Parameter	EF HD-P1-3K-S1	EF HD-P1-3.68K-S1	EF HD-P1-4.6K-S1	EF HD-P1-5K-S1	EF HD-P1-6K-S1
Off-grid power	3000 W	3680 W	4600 W	5000 W	6000 W

SUPPORTED POWER GRID TYPES



I Schematic Diagram



I System Operating Mode

During normal operation, circuit breakers QF1, QF3, QF4, and QF5 must be switched ON, while QF2 must be switched OFF.

On-grid mode

When the utility grid is operating normally, the system will automatically transition to on-grid operation. Relay K1 and K3 will be switched ON automatically while K2 will be switched OFF. In this mode, the utility grid and inverter will supply power to backup/non-backup loads.

Off-grid mode

When the utility grid is abnormal, the system will automatically transition to off-grid operation. Relay K1 and K3 will be switched OFF automatically. In this mode, the backup loads are powered by the inverter, while the non-backup loads lose supply.

Generator backup mode

If the system is equipped with a generator, relay K2 and K3 will be switched ON automatically while K1 will be switched OFF.

- **Generator Start:** If battery SOC < Start Threshold, the generator supplies power to backup/non-backup loads and charges the battery.
- **Generator Stop:** When battery SOC ≥ Stop Threshold, the generator shuts down, and the inverter supplies power to backup loads only.
- **Grid Restoration:** The system automatically reconnects to the grid, resuming on-grid mode.














If a fault is detected

Bypass mode

1. Power off the EcoFlow PowerOcean / OCEAN 2 Plus Single-Phase system. Refer to the inverter installation guide for details.
 2. Switch off QF1, QF3, QF4, and QF5; switch on QF1 and QF2.
- In this mode, the backup/non-backup loads are powered by the grid only; **generator power is unavailable.**

I Preparing Tools and Instruments

-ESSENTIAL TOOLS

						
Hammer drill (with a drill bit of 8mm)	Electrical Screwdriver	Multimeter (DC voltage measurement range \geq 1000 V DC)	Cable cutter	Wire strippers	Screwdriver (PH2)	Crimping tool (for tubular terminal)
						
Heat gun	Marker	Steel measuring tape	Cable tie	Heat-shrink tubing	Level	













-OPTIONAL TOOLS

			
Safety goggles	Safety shoes	Safety gloves	Dust mask

What's In The Box



- Check if the deliverables are intact and complete. If any item is missing or damaged, contact the supplier.
- Retain the original packaging and documentation for further needs.


					
					
					

System Installation

I Installation Space Requirements



- Reserve sufficient clearance around equipments for installation, operation and heat dissipation.
- Please avoid the inverter's heat dissipation path when deploying the system.




I Wall Mount




- The mounting structure where the equipment is installed must be fire resistant. Do not install the equipment on flammable building materials.
- Ensure that the installation surface is solid enough to bear the weight of the equipment.


1




2




3




4



5



6





Electrical Connection



- All electrical connections must be carried out by a professionally trained and certified electrician.
- Device damage caused by incorrect cable connections is not covered by the product warranty.
- Before making electrical connections, ensure that the circuit breaker of the Gateway and all connected external switches are in OFF state. Otherwise, it may cause electric shocks.
- Please purchase cables that meet local certification standards.
- The cable colors shown in the figures are for reference only. Select an appropriate cable according to the local standards.
- Wear PPE and use dedicated insulated tools to avoid electric shocks or short circuits.


I Preparing Cables




No.	Component	Description	From
(A)	EcoFlow Gateway (Single-Phase)	EF-SG1-12K-AU	EcoFlow
(B)	EcoFlow PowerOcean Single-Phase system / EcoFlow Ocean 2 Plus Single-Phase system	<p>Supports connection of up to 2 inverters: EF HD-P1-3K-S1, EF HD-P1-3.68K-S1, EF HD-P1-4.6K-S1, EF HD-P1-5K-S1, EF HD-P1-6K-S1</p> <p>Supports connection of only 1 inverter: EF HD-P1-6K0-S2, EF HD-P1-6K0-S2F, EF HD-P1-8K0-S2, EF HD-P1-8K0-S2F, EF HD-P1-8K0-S2A, EF HD-P1-9K9-S2A, EF HD-P1-10K0-S2, EF HD-P1-10K0-S2F, EF HD-P1-12K0-S2, EF HD-P1-12K0-S2F, EF HD-P1-12K0-S2A</p> <p>Battery: EF BD-5.1-S1, EF BD-5-S2, EF BD-8-S2</p> <p> The Gateway only supports inverters with batteries; those without batteries will not operate properly.</p>	EcoFlow
(C)	PV Inverter	<ul style="list-style-type: none"> • Smart meter is required. • Must be connected to NON-BACKUP / SMART PORT terminal 	A third party
(D)	EcoFlow PowerPulse 2 EV Charger	EF PP-H02-1, EF PP-H02-2, EF PP-H02-3, EF PP-H02-8	EcoFlow
(E)	Utility Meter	/	/
(F)	RCD	An RCD must be installed upstream the backup load. The rated leakage current must be greater than or equal to the number of inverters multiplied by 100 mA.	A third party
(G)	EcoFlow Smart Meter	ADL200N-CT (120A), YDM201D (80A) (For scenario where some of loads connected to the Gateway only.)	EcoFlow
(H)	PV string	A PV string is composed of the PV modules connected in series.	EcoFlow / A third party
(I)	Generator	Select a generator with a rated power of 20 kW or less based on the residential load power and the Gateway requirements.	EcoFlow / A third party
(J)	N-PE Bonding Link	If the Gateway serves as the primary distribution board, the included N-PE bonding link must be installed between the neutral (N) busbar and the protective earth (PE) busbar. This bonding link is prohibited at downstream distribution points.	EcoFlow
(K)	AC Breaker	A 63A-rated AC breaker must be installed upstream of the non-backup load.	A third party
No.	Cable	Type	Recommended Specifications
1	Inverter signal cable	Two-core Shielded Twisted Pair cable	S: 0.5 mm ² , D: 5 mm to 9 mm, length ≤ 30m
2	Inverter AC input power cable (INV1/INV2)	Three-core copper cable	S: 10 mm ² to 16 mm ² , D: 13 mm to 25 mm
3	AC output power cable for non-backup load	Three-core copper cable	S: 10 mm ² to 16 mm ² , D: 13 mm to 25 mm
4	Smart meter signal cable	Two-core Shielded Twisted Pair cable	S: 0.5 mm ² , D: 5 mm to 9 mm, length ≤ 30m
5	Grid power cable	Three-core copper cable	S: 10 mm ² to 16 mm ² , D: 13 mm to 25 mm
6	AC output power cable for the backup load	Three-core copper cable	S: 10 mm ² to 16 mm ² , D: 13 mm to 25 mm
7	Generator power cable	Three-core copper cable	S: 10 mm ² to 16 mm ² , D: 13 mm to 25 mm
8	Generator signal cable	Multi-core Shielded Twisted Pair cable	S: 0.2 mm ² to 1 mm ² , D: 5 mm to 9 mm, length ≤ 30m
9	EV charger signal cable	Two-core Shielded Twisted Pair cable	S: 0.5 mm ² , D: 5 mm to 9 mm, length ≤ 30m
10	EcoFlow OCEAN 2 Plus Hybrid Inverter Single-Phase signal cable	Network cable	Shielded CAT 5 or higher rating, length ≤ 30m For EcoFlow OCEAN 2 Plus Hybrid Inverter (Single-Phase) only. Not required for EcoFlow PowerOcean Single-Phase Hybrid Inverter.

I Recommended Routing


If necessary, remove the bottom protective covers and install the included cable glands.



OPTION 1: BOTTOM WIRING




OPTION 2: BACK WIRING
IF THE BACK CABLE ENTRY IS ADOPTED, THE ENTRY HOLE NEEDS TO BE WATERPROOFED.



I Opening the Maintenance Compartment




- Before maintenance, power off the main circuit breaker, the inverter, and the DC switches of the inverter and battery.
- Do not operate the bypass switch during site deployment or normal use.



Connecting Power Grid / Backup household loads / Non-Backup household loads / Smart Load / Generator




- Select a waterproof rubber plug with the corresponding cable diameter.



Installing the Signal Cable

COM TERMINAL DEFINITIONS



J16	Definition	Used for
PIN1	RS485A0_B	Ecosystem Appliances
PIN2	RS485A0_A	
PIN3	RS485A1_B	VPP communication
PIN4	RS485A1_A	
PIN5	RS485A2_B	EcoFlow Smart Meter
PIN6	RS485A2_A	

J17	Definition	Used for
PIN1	CAN0H	PCS_CAN
PIN2	CAN0L	
PIN3	CAN1H	EMS_CAN
PIN4	CAN1L	
PIN5	CAN2H	Ecosystem Appliances
PIN6	CAN2L	

J23	Definition	Used for
PIN1	Backup	On-grid/off-grid switchover signal
PIN2	SYN	Frequency synchronization signal
PIN3	GND	Signal grounding
PIN4	/	/
PIN5	INT-12V	External 12 V input
PIN6	GND-INT	Signal grounding



J18	Definition	Used for
PIN1	DO-12	Generator 2-wire start
PIN2	DO-11	
PIN3	DO-22	Dry contact output
PIN4	DO-21	SG-READY 1
PIN5	DO-32	Dry contact output
PIN6	DO-31	SG-READY 2


J20	Definition	Used for
PIN1	DI_IN0	DRM0
PIN2	DI_IN1	ATS
PIN3	DI_IN2	
PIN4	DI_IN3	Reserved
PIN5	DI_IN4	
PIN6	GND	Signal grounding

INSTALLING THE COMMUNICATION CABLES BETWEEN INVERTERS AND GATEWAY



- Insert a terminating resistor (included) for proper communication.






PIN9-11: Terminating Resistor


INSTALLING INVERTER (OCEAN 2 PLUS)-GATEWAY COMMUNICATION CABLES



- When the PAR-OUT port is connected to the gateway, other devices that need to communicate with OCEAN 2 Plus via this interface can be connected to the system through a network switch. Supported protocols: Modbus/TCP, FCR and EEBus.




INSTALLING THE SIGNAL CABLE OF ECOFLOW EV CHARGER




INSTALLING THE GENERATOR START SIGNAL CABLE




- The generator to be connected must have its N-PE link connected; otherwise, it may cause the RCD to trip.
- When starting with just a generator in an off-grid setup, the EcoFlow PowerOcean Single-Phase system cannot be woken up by the generator. Press and hold the BATTERY ON/OFF button on the inverter for 10 seconds to activate the battery first, then turn on the generator to allow it to take over.
- If the generator's operating frequency fluctuates excessively, the system will switch to off-grid supply for safety reasons.




(OPTIONAL) ENERGY METERING INSTALLATION FOR SYSTEM WITH THIRD-PARTY PV INTEGRATION



METER with CT: ADL200N-CT (120A)



METER without CT: YDM201D (80A)



System Commissioning


I Check Before Power-On

Check Item	Acceptance criteria
<input type="checkbox"/> Equipments	Equipments are installed correctly and securely.
<input type="checkbox"/> Grounding	The PE cable is connected correctly, securely, and reliably.
<input type="checkbox"/> Switch	All the switches connecting to the system are in OFF position.
<input type="checkbox"/> Cable connection	Please make sure there are no exposed cables in the entire system.
<input type="checkbox"/> Unused terminals and ports	Unused terminals and ports are locked by waterproof glands.

I Closing the Maintenance Compartment



- Before closing the maintenance compartment, remove tools and unused screws from the maintenance compartment.
- Keep the delivered keys properly for future use.



I System Power-On




- Wear PPE and use dedicated insulated tools to avoid electric shocks or short circuits.
- Do not switch on the bypass switch (QF2) during site deployment or normal use.



- To ensure you can verify correct installation immediately after setup, install this product only when the utility grid is present and power on the device using grid supply to activate it.

1. Switch on QF3 and QF4 (Inverters).
2. Switch on QF5 (Generator/PV inverter/load (if any)).
3. Switch on QF1 (GRID).
4. Wait for the inverter and battery to power on; observe the LED to check the inverter and battery operating status.
5. Upon system power-up, access the Pro App for EcoFlow PowerOcean Single-Phase / EcoFlow OCEAN 2 Plus Single-Phase, navigate to the settings interface, and toggle "Connected to gateway" to enable the gateway functionality. This enabling switch is factory-set to the disabled state by default.



System Maintenance

I System Power-Off



- Only authorized personnel can open the maintenance compartment cover to perform maintenance operation.
- Before maintenance, power off the main circuit breaker, the inverter, and the DC switches of the inverter and battery.
- Before maintenance, power off backup load circuit breaker, grid AC circuit breaker, and 2 inverter AC circuit breakers.
- After the system powers off, the remaining electricity and heat may still cause electric shocks and body burns. Therefore, put on protective gloves and begin operating the equipment five minutes after the power-off.
- Wait at least 1 minute after a circuit breaker trips (goes OFF) before trying to reset it (switch it ON) to allow the device and circuit to cool down, stabilize, and prevent damage from repeated tripping, which indicates overload or fault. Repeatedly flipping it quickly can cause damage to the device.

1. Power off the EcoFlow PowerOcean Single-Phase / EcoFlow OCEAN 2 Plus Single-Phase via EcoFlow app or EPO (if any).
2. Switch off QF1, .
3. Switch off QF3, QF4 and QF5 (if any).
4. Use a multimeter to check that no AC voltage in the gateway is present.

I Routine Maintenance


Daily Inspection Items	Appearance Inspection	<ul style="list-style-type: none"> • Cabinet body without deformation/rust/damage, paint intact • Cabinet door closed tightly, locks and identification in good condition • Grounding terminal connected firmly, grounding wire without breakage
	Operation Status Monitoring	<ul style="list-style-type: none"> • Voltage within $\pm 5\%$ of rated value • Current not exceeding circuit breaker rated value • No abnormal noise, peculiar smell or overheating • Indicator lights functioning normally (power/operation lights, etc.)
	Key Component Inspection	<ul style="list-style-type: none"> • Circuit breaker: Contacts without ablation, flexible operation • Contactor: Coil without overheating, contacts without arc marks
Regular Maintenance Content	Weekly Maintenance	<ul style="list-style-type: none"> • Clean surface of the gateway and debris within 1m radius • Check ventilation openings for blockages, ensure normal heat dissipation • Test residual current device (press test button)
	Monthly Maintenance	<ul style="list-style-type: none"> • Clean dust inside and outside gateway with brush • Inspect cable joints for overheating discoloration • Tighten connection terminals, clean oxide layer and apply conductive paste
	Quarterly Maintenance	<ul style="list-style-type: none"> • Inspect capacitor cabinet: capacitors without expansion/leakage, good grounding • Measure grounding resistance (should be $\leq 4\Omega$) • Check busbar and lead connection firmness
Special Maintenance Requirements	Safety Device Calibration	Residual current device: Test operation reliability monthly

I Bypass Switch Operating Instructions




- Wear PPE and use dedicated insulated tools to avoid electric shocks or short circuits.
- Do not operate the bypass switch during site deployment or normal use.
- Do not switch on the bypass switch when the power is on. Otherwise, the high voltage may result in electric shocks and damage to the gateway.
- **DO NOT** switch on the bypass switch (QF2) when the generator (if any) is operating, as it may cause equipment damage or electric shock.
- **The bypass switch can only bypass the grid, not the generator (if any).**


- 1** Power off the EcoFlow PowerOcean Single-Phase / EcoFlow OCEAN 2 Plus Single-Phase via EcoFlow app or EPO (if any).




- 2** Switch off QF1.




- 3** Switch off QF3, QF4 and QF5 (if any).



- 4** Remove the latch on QF2



- 5** Switch on QF1 and QF2.



Technical Parameters

General Data	
Model	EF-SG1-12K-AU
Dimensions	465 x 380 x 160 mm
Weight	14.8 kg
Installation	Wall Mount
Bypass operation mode	Manual
Communication	Ethernet / RS485 / CAN / DI/DO
DC output	12V _{dc} /8 W
Pollution degree	3
Types of earthing system	TN-S/TN-C-S/TT
EMC classification	Class B
External design	Box-type assembly
IK code	IK07
Type of construction	Fixed parts
Type of short-circuit protective device	Circuit breaker
Measures for protection against electric shock	Through the aluminum enclosure
Distribution boards (DBO)	Type A
Grid Connection	
Grid connection type	L/N+PE
Nominal AC voltage	220 V / 230 V / 240 V
Nominal AC current	55 A
Nominal AC power	12 kW
Nominal AC frequency	50/60 Hz
Backup switchover time	0 ms ¹
Inverter Connection	
Inverter 1 Port Rated Current	55 A
Inverter 2 Port Rated Current	27 A
Backup/Non-Backup Port	
Nominal AC voltage	220 V / 230 V / 240 V
Backup Load Current	55 A
Non-Backup Load Current	55 A
Max. Total Load Current (Backup and non-backup load)	55 A
Nominal AC power	12 kW
Nominal AC frequency	50/60 Hz
Overvoltage category	3
Smart Port	
Nominal AC voltage	220 V / 230 V / 240 V
Nominal AC current	55 A
Nominal AC power	12 kW
Generator 2-Wire Auto-Start	Supported
Protection	
Low Voltage Ride Through	Supported
Anti-Islanding	Supported
AC Surge Protection ²	Type II
Environment	
Cooling	Natural Convection ³
Relative Humidity Range	0%~100% RH
Ingress Protection Rating	IP55
Max. Operating Altitude	3000 m ⁴
Operating Temperature	-30°C to 55°C
Storage Temperature	-30°C to 60°C
Environmental Category	Indoor/Outdoor

1. This parameter denotes the load-side transfer interruption duration. To implement this functionality, the gateway must be used in conjunction with the EcoFlow PowerOcean (Single-Phase) / EcoFlow OCEAN 2 Plus Single-Phase system.
Test Conditions: When the utility grid is in an open-circuit state, the rated power of the EcoFlow PowerOcean (Single-Phase) system shall exceed the total power consumption of the backup loads.
2. Should be replaced by a professional.
3. With internal fan assisted.
4. Power may be derated above 2000 m.



PAP

Raccolta carta